

Safety and Maintenance

IMPORTANT

PROTECTIVE EQUIPMENT AND HELMETS FOR ADULT AND CHILD ARE NOT INCLUDED WITH THE LONGBOARDSTROLLER AND NEED TO BE PURCHASED SEPARATELY FROM AUTHORISED DEALERS BEFORE USE.

DISCLAIMER

The Quinny longboardstroller was developed, tested and approved for use in the European Community.

This product was not designed for other territories, notably in to North America, Australia, or New Zealand, and this longboardstroller is not intended for use in those territories.

WARNING

- Never leave your child unattended.
- A child's safety is your responsibility.
- Ensure that all the locking devices are engaged before use.
- To avoid injury ensure that your child is kept away when unfolding and folding this product.
- Do not let your child play with this product.
- Always use the restraint system and foot strap.
- Always wear protective equipment and helmet.
- Always use the safety guard on the bumper bar.
- Always wear the safety leash during use in combination with the engaged emergency brake.
- Not suitable for overnight sleeping, your child may be at risk of serious harm or injury.
- Any load attached to the handle, backrest or sides affects the stability of the longboardstroller.
- To avoid the risk of suffocation, keep all plastic bags and packaging out of reach of babies and young children.
- Always check that the brake is fully engaged before letting go of your longboardstroller.
- Never let your child climb into or out of the longboardstroller alone.
- The tyres may leave marks on some surfaces (particularly smooth floors like parquet, laminate and linoleum).

SAFETY INSTRUCTIONS

1. Using this product is your own responsibility.
2. The longboardstroller is not an indoor product. Only use outside.
3. The longboardstroller seat is intended for children from 12 months and up to 15 kg.
4. The longboardstroller deck is intended for adults up to 100 kg max.
5. Use the longboardstroller for 1 adult and/or 1 child at a time.
6. Wear the following protective equipment: hand/wrist protection, knee protection, head protection and elbow protection (both adult and child).
7. Never lift the longboardstroller with the child inside it.
8. Do not transport children on the longboardstroller deck.
9. The rough surface of the longboardstroller deck may cause damage to your shoes or clothing.
10. Always ride with a closed bumper bar.

11. Always use the transport strap when carrying the folded product.
12. Prevent your child's head, arms and legs sticking outside the seat.
13. Keep both hands on the pushbar during the ride.
14. Respect the local traffic rules.
15. Only ride the longboardstroller forward and during daytime.
16. Never use stairs or escalators with your child in the longboardstroller.
17. The brake must always be on when putting the child in or taking him out. Always use the parking brake, even when standing still for only a few moments!
18. Firmly braking may cause instability of the adult. Use controlled braking.
19. Only use accessories or spare parts sold or approved by the manufacturer. Using other accessories could be dangerous.
20. Any changes to the longboardstroller factory settings could result in dangerous situations.

SAFETY CODE

WARNING

Using the longboardstroller can be dangerous.

- Before using the longboardstroller improve your skills without the child in.
- Prove you are a good longboarder and care about yourself, your child and others.
- Choose to ride in places which allow you to improve your skills, preferably not on pavements or road.
- Ride down gentle slopes only.
- Avoid riding on wet, uneven or slippery surfaces.
- When losing balance don't wait until you fall. Brake, step off and start again.
- Do not exceed 18 km/h.
- Do not perform dangerous tricks.
- Do not use the longboardstroller at a fun-/skatepark.

CLEANING AND MAINTENANCE

- The product must be maintained regularly to provide full satisfaction. We advise you to check and if necessary clean mechanical parts every fortnight.
- Wipe the frame with a clean cloth. Clean and dry thoroughly the chassis, every time you've been in muddy or sandy areas, to avoid rust.
- Do not use grease or oil.
- Your longboardstroller may not work properly if it is not maintained regularly.
- Do not force it if it becomes difficult to fold it up or unfold it. Clean the product.
- If difficulties persist, contact your supplier.
- Caring: Use a sponge and mild soap. Do not use detergent.
- For washing the garment, please consult the instruction label.
- Check the brakes on a regular basis.
- Check that any steering mechanism is correctly adjusted and that the connective components are firmly secured.
- Self-locking nuts and self-locking fixings can lose their effectiveness.
- Replace the wheels and/or cushions when worn out.
- Check the longboardstroller deck for splinters and cracks. Replace the deck when needed.
- Remove any sharp edges created through use.

ENVIRONMENT

- Keep plastic covering away from children to avoid suffocation.
- For environmental reasons, when you have stopped using this product, we ask that you dispose of the product in the proper waste facilities in accordance with local legislation.